


Fluorescent Studio Light Instructions



To assemble the light first carefully unpack the Fluorescent lamp and screw it into the E27 lamp holder.



The fluorescent lamp is designed for use with the softbox supplied. To assemble the softbox see the instruction sheet enclosed with the softbox. For optimum light output do not use the internal diffuser panel. The fluorescent lamp already softens light output. To connect the softbox to the lighting head, insert the bayonet mount into the 3 grooves at the front of the head and turn it in a clockwise direction. The mount will then lock in place behind the spring release clip. To remove the softbox operate the release clip and turn the softbox in an anti clockwise direction.




Release Clip

Stand Fixing



The stand connecting spigot should be in position 'A' and not as shown in 'B' before fitting the studio light to the stand.

Changing Fuses



The fuse (3 Amp) is located in the pull out drawer underneath the mains inlet socket. A spare fuse can also be found in the drawer. Make sure the mains lead has been removed before opening the drawer.